



1. Disassemble the connector if the seat is too thick for your frame. You can easily dismantle the connector by loosening the bolts.



Picture without connector.



2. Now reassemble the seat on your frame.