## How to set the passwordlock



1 The lock is Pre set to 0-0-0.




2 Push the button on the broadside and open the lock



3 Do not release the button and set each number to your selection.



4 Release the button and your number is now set.



**5** Upset all number and press zipper pull into the lock



6 Setup done, now can use new code to open the lock